



## Tailgate Bar Kit Installation Instructions Part #: RT12001

### Kit Contents:

- Tailgate Bar (Qty: 1)
- Tailgate Brackets (Qty: 2)
- Tailgate Bracket Screws (Qty: 4)



### Installation:

1. Ensure all components in the kit are accounted for.
2. Open the tailgate, partially unzip the rear window, and separate the OE tailgate bar from the tailgate brackets.
3. Install the included **Tailgate Brackets** using the included **Screws**. (See Figure 1) The inside edge of the Brackets should be even with the end of the body.

**NOTE:** If the vehicle had no Tailgate Bracket holes, the brackets can be used as templates.



4. Slide the OE Tailgate Bar out of the rear window and install the included Tailgate Bar in its place.
5. Install the **Tailgate Bar** onto the **Tailgate Brackets** and zip the rear window down.

*While every attempt is made to ensure that the information contained in these instructions is correct, no liability can be accepted by the authors for loss, damage, or injury caused by any errors in, or omissions from the information given. All service should be performed by qualified mechanics. Crown Automotive Sales Co., Inc. cannot be held responsible for any mechanical work performed. Standard and accepted safety precautions should be used in every procedure.*