



RT Off-Road Sun Visor Set

Installation Tips

**Part Numbers: RT52001, RT52002, RT52003, RT52004,
RT52005, RT54001, RT54002, RT54003**

NOTE: The mounting bracket built into each sun visor feature an integrated rod that is extendable to allow for the mounting holes to line up with the holes in the body. Simply push or pull the mounting bracket to shorten or lengthen them to achieve the proper bolt spacing to allow for installation.